

PULSE MINI



Quick Setup Guide

bluesound.com

Included Accessories



120V AC Power Cord



230V AC Power Cord



Ethernet Cable



Mini Jack to Toslink Adaptor

PULSE MINI


All-in-one
Wireless Streaming
Music System

English

Português

1

CONNECT TO POWER




A Select the AC Power Cord appropriate for your region and plug it into the Player, and then into your wall outlet.

B The PULSE MINI's LED button should turn Solid Green, indicating that the player is in Hotspot Mode and ready to be added to your home WiFi network.

Never force a power cord into a wall outlet. An adaptor may be necessary in certain regions.

2

CONNECT TO WiFi



A On your tablet or smartphone, **look for the WiFi network (hotspot) matching your PULSE MINI's unique network ID**, and join it. The network ID is listed as the product name (i.e. PULSE MINI) immediately followed by the last four digits in the MAC (Machine Access Control) address (*example: PULSEMINI-001A*). The full 12-digit MAC address is printed on a sticker on the back panel of your Player.

B Open a web browser on your tablet or smartphone and enter **setup.bluesound.com**, and press "Go". A control panel page should then appear.

C From the main menu displayed, select **Configure WiFi**.

D Select **your home WiFi Network** from the **Configure Wireless** drop down menu.

E Enter your home network's **Wireless Password** in the field provided (if it is a protected network).

F Select a **Room Name** from the drop down list, or create a customized Room name in the field provided.

G Press **Update** and wait for the Player's light to turn solid blue, indicating that the Player has successfully joined your home WiFi network.

H Repeat steps A-G for each additional Bluesound Player.

I **Reselect your home WiFi network** from your tablet or smartphone's **main network settings**.

Alternatively, the PULSE MINI can be connected directly to your wired home network or router using the Ethernet cable provided.

To see an instructional video on WiFi Setup, please visit www.bluesound.com

3

DOWNLOAD THE APP



All Bluesound Controller Apps for Apple iOS devices (iPhone, iPad, iPod), Android devices, Kindle Fire, and Windows or Mac desktops are available for download at www.bluesound.com/downloads

Congratulations, your Player setup is complete!


It's time to connect your music. Launch the App for the following playback options.



4

CONNECT TO MUSIC



Your Music : To play music stored on a computer or NAS device, open the Navigation Drawer by tapping  in the App, choose **Configure Player** from the menu, and select **Configure Network Shares**. Follow the screen prompts, and open every Room in your home to your entire digital music library.

Internet Radio : Simply select **TuneIn** from the **Music Services** menu, and find your favorite radio station. Or, explore and discover the thousands of radio stations streaming live 24/7 from anywhere on the planet via **TuneIn**.

For detailed information, please visit www.bluesound.com

Português

1 LIGAÇÃO À ALIMENTAÇÃO

- A Seleccione o Cabo de Alimentação CA adequado para a sua região e ligue-o ao leitor e, em seguida, à tomada de parede.
- B O botão LED do PULSE MINI fica verde, indicando que o leitor está no Modo Hotspot e está pronto para ser adicionado à sua rede Wi-Fi doméstica.

Nunca introduza um cabo de alimentação numa tomada de parede à força. Em determinadas regiões, pode ser necessário utilizar um adaptador.

2 LIGAÇÃO A WI-FI

- A No seu tablet ou smartphone, procure a **rede Wi-Fi (hotspot) que corresponde à ID de rede única do seu PULSE MINI** e efectue a associação. A ID de rede é apresentada como o nome de produto (i.e. PULSE MINI 2) imediatamente seguido pelos últimos quatro dígitos no endereço MAC (Machine Access Control) (exemplo: **PULSEMINI-001A**). O endereço MAC completo de 12 dígitos está impresso num autocolante no painel traseiro do leitor.
- B Abra um navegador de Internet no seu tablet ou smartphone, introduza **setup.bluesound.com** e carregue em "Ir". Deverá aparecer uma página de painel de controlo.
- C A partir do menu principal apresentado, seleccione **Configure WiFi** (Configurar Wi-Fi).
- D Seleccione a sua rede Wi-Fi doméstica a partir do menu pendente **Configure Wireless** (Configurar Sem Fios).
- E Introduza a **Wireless Password** (Palavra-passe Sem Fios) da sua rede doméstica no campo fornecido (no caso de ser uma rede protegida).
- F Seleccione um **Room Name** (Nome de Divisão) a partir da lista pendente, ou crie um nome de divisão personalizado no campo fornecido.
- G Prima **Update** (Actualizar) e aguarde até que a luz da unidade fique azul, indicando que o leitor se associou com êxito à sua rede Wi-Fi doméstica.
- H Repita os passos A-G para cada dispositivo Bluesound adicional.
- I **Volte a seleccionar a sua rede Wi-Fi doméstica a partir das definições de rede principal** do seu tablet ou smartphone.

Em alternativa, pode ligar o PULSE MINI directamente ao seu router ou rede doméstica com fios utilizando o cabo Ethernet fornecido.

Para ver um vídeo de instruções sobre a Configuração Wi-Fi, visite www.bluesound.com

3 TRANSFERÊNCIA DA APLICAÇÃO

Todas as aplicações Bluesound Controller para dispositivos com o sistema iOS da Apple (iPhone, iPad, iPod), dispositivos Android, Kindle Fire e Windows ou Mac Desktop Control estão disponíveis para transferência em www.bluesound.com/downloads.

Parabéns, a configuração do leitor está concluída!

Está na altura de ligar à sua música. Inicie a aplicação para obter as seguintes opções de reprodução.

4 LIGAÇÃO À MÚSICA

Your Music (A Sua Música): Para reproduzir música armazenada num computador ou dispositivo NAS, seleccione o ícone (📁) na aplicação, seleccione **Configure Player** (Configurar Leitor) a partir do menu e seleccione **Configure Network Shares** (Configurar Partilhas de Rede). Siga as instruções no ecrã e abra cada divisão da sua casa a toda a sua biblioteca de música digital.

Internet Radio: Seleccione simplesmente **TuneIn** no menu **Music Services** (Serviços de Música) e encontre a sua estação de rádio favorita. Ou, explore e descubra milhares de estações de rádio que transmitem em directo 24 horas, 7 dias por semana, em todo o mundo através do **TuneIn**.

Para obter informações pormenorizadas, visite www.bluesound.com

BLUESOUND®

© Bluesound International. Bluesound, the stylized wordmark and “B” logotype, the phrase “HiFi for a wireless generation”, PULSE MINI and all other Bluesound product names and taglines are trademarks or registered trademarks of Bluesound International, a division of Lenbrook Industries Limited. All other logos and services are trademarks or service marks of their respective owners.